



Apple Watch Series 3 Battery Disconnection - prereq

Written By: Tobias Isakeit



TOOLS:

iOpener (1)
Curved Razor Blade (1)
iFixit Opening Tool (1)
iFixit Opening Picks (Set of 6) (1)
Tweezers (1)
Tri-point Y000 Screwdriver (1)

Step 1 — Battery Disconnection



- Use a Y000 driver to remove the tri-point screw securing the metal cover plate.
- Use a pair of [tweezers](#) to remove the cover plate.
 - First open the plate all the way to unhinge the two flaps.
 - Then close it halfway to remove it completely by lifting it out.

Step 2



ⓘ On the GPS-only version it is possible to disconnect the battery immediately. For the cellular/LTE version, you need to disconnect the Force Touch gasket and fold it out of the way first, in order to disconnect the battery.

- Disconnect the battery by prying its connector straight up.
- Bend the connector up slightly to make sure it does not make contact by accident.

To reassemble your device, follow these instructions in reverse order.