




Acer Aspire 5742 RAM Replacement

Upgrade the RAM in your Acer Aspire 5742.

Written By: Skylar MacDonald



INTRODUCTION

Upgrade your RAM for a noticeable increase in speed.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)
 - [Scotch tape](#) (1)
- (optional)*
- [Spudger](#) (1)
-

Step 1 — Battery




- Move the battery catch to the "unlocked" position.
- Pull back the second spring-loaded battery catch until the battery pops up.
- Remove the battery.

Step 2 — Cover Panel



- Turn the notebook around to face you.
- There are two Phillips #00 screws securing the cover panel to the rest of the notebook. Remove these screws.

Step 3




- Use a spudger to release the panel from the plastic retaining clips keeping it in place.

⚠ Do not apply too much force, or you may break the clips.


- Remove the panel and set it aside.

Step 4 — RAM




- The RAM is protected by a transparent cellophane cover.
 - Lift this cover away from the RAM. It will not come free from the RAM.
- i* You may wish to use some Scotch tape to hold the cover in place while you work.

Step 5



- Pull back the retaining clips either side of the RAM.
- It will spring up, ready to be removed.

Step 6



- Hold on to opposite edges of the RAM chip and gently pull it diagonally upwards to remove it from the computer.
- Repeat steps 5 and 6 for the second RAM chip if necessary.

Step 7



- When reinserting RAM, push it diagonally downwards until almost all of the gold connector strip is inside the socket.
- Push gently down on the RAM until the retaining clips click back over it.

To reassemble your device, follow these instructions in reverse order.