



Floor Pump Gauge Replacement

Replace the pressure gauge in your classic floor drive pump.

Written By: iRobot



INTRODUCTION

Replace the pressure gauge in your classic floor drive pump if the gauge appears to be inaccurate, is malfunctioning or has stopped working all together.

TOOLS:

- [Flathead Screwdriver](#) (1)
- [Loctite](#) (1)
Green, 290
- [Large Needle Nose Pliers](#) (1)

PARTS:

- [Replacement Classic Floor Drive Pump Gauge](#) (1)
0-160 psi | 0-11 BAR

Step 1 — Removing the Gauge Cover



- Using a flat head screwdriver, pry up an edge of the gauge cover.
- Remove the gauge cover.

Step 2 — Removing the Gauge Face Plate and Internals



i No parts from the old gauge will be re-used, so there is no need to attempt to preserve the parts. However, be careful not to damage the gauge housing.

- Pry up a corner of the gauge face plate.
- Use pliers to pull off the gauge face plate.
 - ⚠** Be careful not to cut yourself when prying off the face plate, as the edges are sharp.
- Use pliers to pry out the internal gauge mechanics.

Step 3 — Removing the Old Gauge



- Using pliers, grip the exposed brass piece and unthread the gauge by rotating it counter-clockwise.
- Pull the gauge out of its housing.

Step 4 — Replacing the Gauge O-rings



- Remove the O-ring at the bottom of the threaded hole.
- Place a new O-ring into the hole.

Step 5 — Applying Threadlocker



- Apply medium-strength Loctite (green, 290) to the threads on the new gauge.
- ⓘ Apply a thin layer, but make sure it covers all the threads.

Step 6 — Installing the New Gauge



- Thread the new gauge into the floor pump by turning it clockwise in its housing.
- Thread the gauge until it is snug and the BAR/psi markings are aligned with the pump body.
- ⓘ Gauge performance will not be affected by its position, so long as it is snug.
- Allow at least 30 minutes for the thread locker to set.
- Test the pump to its highest rated pressure and listen for leaks. If you can hear leaks from the gauge, tighten it.