



Jensen JTA-230 Cartridge/Needle Replacement

This document will show you the proper way to replace the part for the Jensen JTA-230 turntable.

Written By: Louis Varrichione



INTRODUCTION


The record player is a device used to play music out loud using records. The process by which the device creates sounds is very simple. The record is placed on a turntable, and is continuously rotated. While this happens, a stylus senses grooves cut into the record. This creates vibrations which are in turn converted into electrical signals, and then into audible sound. The replacement of the cartridge and needle is one of the easier pieces to replace. In addition, no specific tools are reacquired to fix the issue.

Step 1 — Cartridge/Needle




- Open the dust cover

Step 2



- Next, lift up the clip that holds the tone arm in place and lift the tone arm out.

Step 3



- The cartridge and needle is the red piece at the end of the tone arm. To remove it, simply grab the end on each side and pull back slowly. The piece should slide right off the tone arm

Step 4



- Once you have the replacement piece it goes on slight different. Instead of it sliding back on, it clips back on. Once the new piece is secured back on it is good to go.

To reassemble your device, follow these instructions in reverse order.