



3DR Solo Leg Replacement

This is a guide to show how to remove the legs on the drone if needed.

Written By: Leia Harlow



INTRODUCTION

This guide shows how to remove the legs on the bottom of the drone.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Propeller



- Grip the arm, which is located underneath the propeller, with one hand, and with your dominant hand grip the center of the propeller.

Step 2



- Twist the propeller from the locked to unlocked position as indicated by the images of the lock.
- ⓘ You will need to twist in this direction for 2-3 full rotations before the propeller will detach.

Step 3



- Lift the propeller off the motor.
- ⓘ To remove the silver-top propellers, repeat these steps, turning the propellers in the opposite direction of the black-top propellers.

Step 4 — Leg



- Place the controller on a flat surface with the battery side down.

Step 5



- Locate the leg and remove the two 10mm screws that hold the leg in place.

Step 6



- Gently pull the leg up to remove it from its position.
- ⓘ Leg should be connected by a black wire.

Step 7



- Locate the rubber grip at the end of the leg and, with your thumb, peel it back and pull it off.


Step 8



i Leg type 1 will contain a 1mm screw at the base of the leg.

- Unscrew the 1mm screw located at the end of the leg.

Step 9



- Gently pull the black cord up to release it from the leg.

Step 10



i Leg type 2 will contain the antenna wire.

- Gently pull up on and remove the plastic covering labeled "solo antenna".
- Locate the antenna wire and carefully pull up and remove it.

! The antenna wire is flimsy so use caution upon removal.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-27 06:06:13 PM (MST).

