



# Installing PowerBook G4 Titanium Mercury Keyboard

## Parts relevant to this guide

- [G4 Titanium Mercury Keyboard](#) (1)

Replacing this keyboard is easy. It requires no tools, and takes only a few minutes.



## Step 1 - Keyboard

- Remove the battery.
- Turn the keyboard locking screw so that it is parallel to the space bar.
- Pull the keyboard release tabs toward you and lift up on the keyboard until it pops free.



## Step 2

- Rest the keyboard face down on the trackpad area.
- Disconnect the keyboard connector from the logic board.



## Step 3

- Your laptop should look approximately like this.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on Dec 13, 2010.

# G4 Ti Mercury Screw Guide

