



Installing iBook G3 14" Battery

Author: iRobot

Tools used in this guide

- [Coin](#) (1)

Parts relevant to this guide

- [iBook G3 14" Battery](#) (1)

Changing the battery is easy -- all you need is a coin.



Step 1 — Battery


- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.


This document was last generated on Feb 23, 2012.




↓



Keyboard
2 Phillips Screws




Lower Case (under feet)
3 Phillips




Lower Case
2 T8 Torx


↓




Lower Case
1 T8 Torx



Lower Case (battery compartment)
2 Phillips



Upper Case bottom (red)
3 Phillips



Upper Case bottom (orange)
3 Phillips


↙ ↘



To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.


If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.

Due to model variations, the screws you remove may differ slightly from this guide.




Upper Case bottom (yellow)
3 Phillips

↓



Upper Case top (red)
2 Phillips




Upper Case top (orange)
1 Phillips




Bottom Shield (red)
1 Phillips

↓



Bottom Shield (orange)
9 Phillips





Fan
1 Phillips





Top Shield (red)
5 Phillips









Top Shield (orange)
3 Phillips



Top Shield (yellow)
8 Phillips



Modem
2 Phillips



Hard Drive
1 Phillips

HD Replacement
4 T8 Torx

Optical Drive
2 Phillips



Optical Drive (cable)
2 Phillips





To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.

If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.



Due to model variations, the screws you remove may differ slightly from this guide.



IO Bezel
1 Phillips



DC-In Board
1 Phillips



Display (data cable)
2 Phillips



Display
2 Phillips

Logic Board (red)
2 Phillips

Logic Board (orange)
2 Phillips

Logic Board (yellow)
1 Phillips



