



# Installing iBook G3 12" Rear Display Bezel

Author: Ben Eisenman

## Tools used in this guide

- [1.5mm Hex Screwdriver](#) (1)
- [Coin](#) (1)
- [Spudger](#) (1)

## Parts relevant to this guide

- [iBook G3 12" Rear Display Bezel \(Translucent white\)](#) (1)
- [iBook G3 or G4 12" Rear Display Bezel \(Opaque white\)](#) (1)

Remove your rear display bezel to access your display's internals.



## Step 1 — Battery

- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.



## Step 2 — Rear Display Bezel

- Use a 1.5mm hex screwdriver to remove the two hex screws on either side of the display (four screws total).
- If you don't have a 1.5mm hex driver, you can probably get these screws out with a T6 Torx screwdriver. However, if you use a T6 Torx driver you'll be more likely to strip the screws.



## Step 3

- Insert the flat end of a spudger perpendicular to the face of the display into the gap between the front and rear bezels near the upper left corner of the display.
- Rotate the spudger away from the display to pry the rear bezel off the front bezel.



## Step 4

- Run your spudger along the top edge of the front display bezel to evenly separate the two bezels.



## Step 5

- Working down from the upper left corner, use the flat end of a spudger to pry the rear bezel away from the left edge of the display.



## Step 6

- Use the flat end of a spudger to pry the rear bezel away from the right edge of the display.
- If necessary, pry along the bottom edge of the rear bezel to separate it from the display assembly.



## Step 7

- Lift the rear bezel off the display assembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on Feb 26, 2012.