



Installing iBook G4 14" 933 MHz-1.33 GHz Battery

Author: iRobot

Tools used in this guide

- [Coin](#) (1)

Parts relevant to this guide

- [iBook G4 14" Battery](#) (1)

Changing the battery is easy -- all you need is a coin.



Step 1 — Battery

- Use a coin to rotate the battery locking screw 90 degrees clockwise.



Step 2

- Lift the battery out of the computer.

Installing iBook G4 14" 933 MHz-1.33 GHz Battery

To reassemble your device, follow these instructions in reverse order.

This document was last generated on Feb 23, 2012.



↓



RAM Shield
4 Phillips Screws



Lower Case (under feet)
3 Phillips



Lower Case
1 T8 Torx


Lower Case
2 T8 Torx

↓


Lower Case (battery compartment)
2 Phillips


Bottom Shield (red)
6 Phillips


Bottom Shield (orange)
3 Phillips


↙ ↘




To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.


If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.


Due to model variations, the screws you remove may differ slightly from this guide.


Bottom Shield (yellow)
1 Phillips


↓



DC-In Board
1 Phillips



Battery Connector
2 Phillips


Upper Case (bottom - red)
3 Phillips

↓


Upper Case (bottom - orange)
3 Phillips



Upper Case (bottom - yellow)
1 Phillips



Upper Case (bottom - green)
4 Phillips


↓





↓


 Upper Case (top)
1 Phillips


 Upper Case (top)
2 Phillips

 Sleep Light
1 Phillips

 Top Shield (red)
13 Phillips

 Top Shield (orange)
1 Phillips

 Top Shield (yellow)
2 Phillips

 Modem
2 Phillips

↙ ↘





To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.


If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.


Due to model variations, the screws you remove may differ slightly from this guide.


↓


 Hard Drive
4 Phillips


 Hard Drive Replacement
4 T8 Torx

 Optical Drive (red)
1 Phillips

 Optical Drive (orange)
1 Phillips

 Optical Drive (yellow)
1 Phillips


 I/O Bezel
1 Phillips

 I/O Bezel
1 Phillips


↓



↓



Display
2 Phillips



Hinge Grill
1 Phillips



Hinge Grill
1 Phillips


↓




Heat Sink (black)
1 Phillips



Heat Sink (red/orange)
4 Phillips



Heat Sink (yellow)
1 Phillips



Heat Sink (green)
1 Phillips


↙ ↘




To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.

If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.


Due to model variations, the screws you remove may differ slightly from this guide.



Heat Sink (blue/purple)
1 nut, 2 standoffs




Fan
4 Phillips




Logic Board (top)
1 Phillips


↓




Logic Board (red)
2 Phillips



Logic Board (orange)
1 Phillips



Logic Board (yellow)
1 Phillips



Logic Board (green)
4 Phillips

↓

