



Installing PowerBook G4 Titanium Mercury Keyboard

Author: iRobot

Parts relevant to this guide

- [G4 Titanium Mercury Keyboard](#) (1)

Replacing this keyboard is easy. It requires no tools, and takes only a few minutes.



Step 1 — Keyboard

- Remove the battery.
- Turn the keyboard locking screw so that it is parallel to the space bar.
- Pull the keyboard release tabs toward you and lift up on the keyboard until it pops free.



Step 2

- Rest the keyboard face down on the trackpad area.
- Disconnect the keyboard connector from the logic board.



Step 3

- Your laptop should look approximately like this.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on Feb 23, 2012.

G4 Ti Mercury Screw Guide

