



Installing PowerBook G4 Titanium DVI Airport Card

Author: iRobot

Tools used in this guide

- [T8 Torx Screwdriver](#) (1)

Parts relevant to this guide

- [Airport Card](#) (1)

Install an original Airport 802.11b card internally.



Step 1 — Battery

- Locate the battery release tab on the underside of the G4.
- Slide the battery release tab to the left and lift the battery out of the computer.



Step 2 — Lower Case

- Remove the seven T8 Torx screws from the lower case.



Step 3

- Using your thumbs, slide the lower case away from you.
- The lower case may stick in the front on a tab just above the center of the optical drive. Be careful as you work the case off, or you may break the thin strip of plastic just above the drive.
- Lift the lower case off.



Step 4

- Your laptop should look approximately like this.



Step 5 — Airport Card



- Firmly grasp the plastic tab attached to the Airport card and pull up and to the left.
- Disconnect the antenna cable from the left side of the Airport card.

To reassemble your device, follow these instructions in reverse order.



This document was last generated on Feb 23, 2012.





↓



Lower Case
7 T8 Torx





Hard Drive
2 T8 Torx





HD Replacement
2 T8 Torx



↓





Optical Drive
2 T8 Torx



Modem
2 T6 Torx



Inverter
2 T6 Torx



DC-In Board
2 T6 Torx



↙ ↘



To organize your screws, simply place each screw in the appropriate box as you remove them from your laptop.



If you are not planning on immediately reassembling your laptop, you may want to tape the screws to this paper.

Due to model variations, the screws you remove may differ slightly from this guide.





Modem Filter Board
1 T8 Torx



↓



Modem Filter Board
1 T6 Torx





Logic Board
5 T8 Torx





Logic Board
1 T8 Torx



↓



Logic Board
1 T8 Torx



PC Card Cage
1 T8 Torx



PC Card Cage
1 T8 Torx

