



Motorola Q Global Battery Replacement

Instructions for removing and installing the lithium ion battery. This is a preliminary step for most repairs and installations.

Written By: Will Dickman



INTRODUCTION

This guide details the steps necessary to remove the battery for replacement or for further disassembly of the Q Global. Removing or replacing the battery can solve issues related to the battery such as failure to charge and unresponsiveness.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Turn the phone face down.
- Press and hold the release button in the middle of the back panel.
- Slide the bottom panel down to remove.

Step 2



- Remove the battery pack by prying it out with a fingernail, screw driver or other opening tool at the tab shown.

⚠ When reinserting the battery, make sure the contacts in the battery are lined up with the contacts in the phone.

To reassemble your device, follow these instructions in reverse order.