

Samsung Galaxy Tab E 8.0 Motherboard Replacement

The motherboard of the Samsung Galaxy Tab E 8.0...

Written By: Christian Bloemhof



INTRODUCTION

The motherboard of the Samsung Galaxy Tab E 8.0 may malfunction after overuse of the device. This guide will show how to replace the tablet's motherboard, which is attached to the front panel.



TOOLS:

iFixit Opening Tool (1) Tweezers (1) JIS #00 Screwdriver (1)


Step 1 — Back Panel



• Use the iFixit Opening Tool to pry off the back case, moving the tool around the screen.

⚠ Make sure the device is off and the SD card is removed before taking off the back casing.

Step 2 — Back Camera




- Use the <u>tweezers</u> to lift the switch connecting the back camera to the motherboard.
- Use your hand to remove the back camera from the motherboard.

Step 3 — Front Camera




- Use the <u>tweezers</u> to lift the switch connecting the front camera to the motherboard.
- Remove the front camera from the motherboard by lifting with the tweezers.

Step 4 — Motherboard






- Use the <u>tweezers</u> to flip the switch on the bottom of the strap that goes over the battery.
- Release the strap from the switch by lifting the strap with your hand.







- Use the tweezers to flip the switch that connects the top of the strap to the motherboard.
- Lift the top end of the strap with your hand and remove the strap completely from the device.




- Use the tweezers to flip the switch of the connector.
- Lift the connector from the motherboard.
- *i* This connector does not come completely off, but disconnects from the motherboard.



- Use the tweezers to flip the switch of the blue connector on the motherboard.
- Lift the connector from the motherboard.
- *i* This switch can detach from the device, but just needs to disconnect from the motherboard.
- (i) Ensure the blue ribbon cable is not under the motherboard upon reassembly.



- Use the tweezers to flip the switch of the connector that runs from the battery to the motherboard.
- Lift the connector from the motherboard.
- *i* This switch can detach from the device, but just needs to disconnect from the motherboard.





- Use a JIS #00 screwdriver to remove the six 4.5mm screws at the top of the motherboard.
- Lift the motherboard with your hand to detach the motherboard from the device.

To reassemble your device, follow these instructions in reverse order.