

Razer Blade RZ09-0102 Battery Replacement

This guide will show you how to remove and replace a faulty battery for the Razer Blade RZ09-0102.

Written By: Nicole Schukow



INTRODUCTION

A guide to remove and replace the battery for the Razer Blade RZ09-0102. You may want to replace your battery if the battery cannot hold a charge or drains after an unreasonably short time. The battery needs to be removed if working on other components as well.



TOOLS:

- T5 Torx Screwdriver (1)
- iFixit Opening Tools (1)
- Phillips #0 Screwdriver (1)



PARTS:


 Razer Blade RZ09-0102 Replacement Battery (1)

Step 1 — Rear Panel



- Before you begin, be sure to turn off your laptop.
 - Using a Torx T5 screwdriver, remove the ten 1/8 inch screws securing the back cover.
 - Remove the back cover.

Step 2 — Battery





Remove the seven screws holding the battery in place using a Phillips #0 screwdriver.

Step 3



- Unlock the ZIF connectors securing the right ribbon cable.
 - To unlock a <u>ZIF connector</u>, use an opening tool or your fingernail to flip up the small, hinged locking flap.
- Carefully pull the two ribbon cables out of their sockets.


Step 4



 Use an opening tool to unlock the ZIF connector securing the white ribbon over the battery.

Step 5





- Carefully pull out the two connectors out of their sockets.
 - Pull parallel to the motherboard, not straight up.


Step 6





- Pull the wide battery connector towards the battery to disconnect it from the motherboard.
 - Pull parallel to the motherboard, not straight up.

Step 7





Remove the battery from the laptop.

To reassemble your device, follow these instructions in reverse order.

For optimal performance, after completing this guide, <u>calibrate</u> your newly installed battery.

Take your e-waste to an R2 or e-Stewards certified recycler.

Repair didn't go as planned? Try some basic troubleshooting, or ask our Answers community for help.