



# Nexus 5X SIM Card Tray Replacement

This guide shows you how to remove the SIM card tray from your Nexus 5X.

Written By: Tobias Isakeit



---

## INTRODUCTION

Use this guide to remove the SIM card tray from your Nexus 5X.

---

### TOOLS:

- [SIM Card Eject Tool](#) (1)
-

## Step 1 — SIM Card Tray



- Insert a SIM card ejection tool into the hole on the SIM card tray, located on the left edge of the phone.
- Press in to eject the SIM card tray.
- Remove the SIM card tray.

To reassemble your device, follow these instructions in reverse order.