



Lenovo ThinkPad T440p Battery Replacement

Use this guide to replace the battery for the Lenovo ThinkPad T440p.

Written By: Christian Abad



INTRODUCTION

If you have a drained or dead battery, use this guide to replace it in the Lenovo ThinkPad T440p. The procedure does not require any tools or present any danger to the device or the person performing the replacement.



PARTS:

- [Lenovo 45N1151 Battery](#) (1)
-

Step 1 — Battery



- Flip the laptop so that the back is facing up.

Step 2



- Slide the battery latches to the unlocked position.

Step 3



- Slide the battery pack out of the battery slot.

To reassemble your device, follow these instructions in reverse order.