

Milwaukee 5262-21 Housing Assembly Replacement

Use this guide to remove the housing assembly in your Milwaukee 5262-21.

Written By: Adrien Andrade-Cain



This document was generated on 2020-11-28 07:26:22 AM (MST).

INTRODUCTION

Follow this guide to replace the Housing Assembly on your Milwaukee 5262-21 . You will be able to look at pictures, that will be useful in order to see which screws need to be removed.

TOOLS:	PARTS:
 T20 Torx Screwdriver (1) 	 Milwaukee 5262-21 Housing Assembly (1)

This document was generated on 2020-11-28 07:26:22 AM (MST).

Step 1 — Housing Assembly



Remove the ten 19mm T20 Torx screws shown in red.

Step 2



• Remove the red Housing Assembly by lifting it up off of the tool.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 07:26:22 AM (MST).