iPhone 11 Pro Max Logic Board Replacement

How to remove and replace the logic board on the iPhone 11 Pro Max

Written By: Arty

This document was generated on 2022-03-13 06:54:34 PM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 1 of 3

INTRODUCTION

[video: https://www.youtube.com/watch?v=Rn85i2BxNfI]

How to remove and replace the logic board on the iPhone 11 Pro Max.

Note: Each iPhone's logic board and Face ID + proximity sensor are paired at the factory, so replacing the logic board will disable Face ID *unless* you also install a replacement Face ID module + proximity sensor that has been properly paired to your new logic board.

TOOLS:

- Suction Handle (1)
- Spudger (1)
- Tweezers (1)
- iFixit Opening Picks (Set of 6) (1)
- Phillips #000 Screwdriver (1)
- P2 Pentalobe Screwdriver iPhone (1)
- Tri-point Y0 Screwdriver (1)
- Standoff Screwdriver for iPhones (1)

This document was generated on 2022-03-13 06:54:34 PM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2022-03-13 06:54:34 PM (MST).

www.iFixit.com Page 3 of 3