

Backbone One Right Mainboard Replacement

How to replace the mainboard on the right controller handle in your Backbone One.

Written By: Adriana Zwink



INTRODUCTION

Use this guide to replace the mainboard on the right controller handle in your Backbone One.

TOOLS:

- Phillips #0 Screwdriver (1)
- ESD Safe Tweezers Blunt Nose (1)
- iFixit Opening Picks set of 6 (1)

Step 1 — Remove the screws



• Use a Phillips screwdriver to remove the four 5.9 mm-long screws.

Step 2 — Rotate the upper part



- Lift up the upper cover of the controller.
- Swing the upper cover over and place it on the controller case.

Make sure that the interconnecting cable has no tension.

Step 3 — Remove the protective tape




 Use a pair of tweezers to remove the yellow protective tape which is placed over the interconnect cable and the connector.

Step 4 — Open the interconnect cable ZIF connector




• Use the tip of an opening pick to open the gray flap of the interconnect cable ZIF connector by pushing it upwards.

Step 5 — Disconnect the interconnect cable



• Disconnect the cable by pulling it straight out the ZIF connector.

Step 6 — Disconnect the phone connector cables



• Use a pair of tweezers to disconnect the phone connector cables out from their sockets.

Step 7 — Separate the upper case




• Separate the the upper case of the left controller handle.

Step 8 — Remove the screws




• Use a Phillips screwdriver to remove the three 5.9 mm-long screws.

Step 9 — Remove the trigger



• Remove the trigger.

Step 10 — Remove the bumper



• Remove the bumper.

Step 11 — Remove the screws



• Use a Phillips screwdriver to remove the two 3.9 mm-long screws.

Step 12 — Remove the mainboard



• Remove the mainboard.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an <u>R2 or e-Stewards certified recycler</u>.

Repair didn't go as planned? Ask our <u>Answers community</u> for help.