



Logitech M570 Wireless Trackball Mouse Disassembly

Written By: Peter Scholl



TOOLS:

Kreuzschraubendreher (1)

Step 1 — Remove the screws



- Unscrew 5 screws, which are partially hidden. Three screws are located under the rubber buffers and one in the battery compartment under the sticker (which should then be loosened beforehand).
- You can simply push the blue trackball out of its holder. You should also do this occasionally and clean the opening.

Step 2 — The Interior



- After the screws are loosened, the housing can be easily removed. The space for the blue ball is made of its own piece of plastic. The circuit board is held in place with a few screws.

Work through the steps in reverse order to reassemble your device.