# Lenovo Yoga C930-13IKB Fingerprint Reader Replacement

This guide includes all the steps, tools, and...

Written By: Elizabeth Miller



## INTRODUCTION

This guide includes all the steps, tools, and parts necessary to disassemble the Lenovo Yoga C930-13IKB to access and replace the fingerprint reader.

**TOOLS:**

T5 Torx Screwdriver (1)
iFixit Opening Tool (1)
Phillips #00 Screwdriver (1)
Tweezers (1)

**PARTS:**

Lenovo Yoga C930-13IKB Fingerprint Reader (1)

### Step 1 — Back Cover



- Flip the device over so that the underside is facing up.
- Remove the six 3.5 mm T5 Torx screws.

## Step 2





- Pry off the back cover using the plastic opening tool.
- Loosen the back cover in multiple spots using the opening tool, then remove the whole back.

ⓘ You may have to run the plastic tool along the edges until you find a small gap to separate the back cover from the laptop.

⚠ Do not use a metal tool when working with your device.

## Step 3






- Carefully lift the cover off with your hands.

## Step 4 — Battery








- Unplug the battery from the motherboard by pinching the cables with your fingers and tugging out with force.

ⓘ Use the spudger for assistance.

## Step 5




- Unscrew the four 3mm screws with a Phillips screwdriver.

## Step 6







ⓘ The battery is still held in place with two stretch-release adhesive strips, [similar to ones found in an iPhone.]


- Use your fingers to pry up the clear plastic pull-tab for one of the stretch release adhesives.
- Grasp the pull-tab and slowly pull away from the battery at a shallow angle. The adhesive strip will stretch to many times its length and slowly release from underneath the battery.
- Repeat the procedure for the second strip on the opposite side of the battery.

⚠ Be careful not to bend the battery. Breaking the battery is dangerous.

- Remove the battery with your hands.


## Step 7 — Fingerprint Reader





- Remove the single 2 mm screw from the fingerprint reader cover plate using the Phillips #00 screwdriver.
- Gently lift and slide out the cover plate using a pair of angled ESD tweezers.




## Step 8





- Using the angled ESD tweezers, gently lift the black tab on top of the ZIF connector on the fingerprint reader.
- Gently pull the ribbon cable out from the connector using the tweezers.

## Step 9

- Lift and remove the fingerprint reader from the laptop using the angled ESD tweezers.

---

To reassemble your device, follow these instructions in reverse order.