



# Valve Index Headset Head Strap Clip Replacement

How to replace the head strap clip on a Valve Index VR headset.

Written By: Sam Omiotek



# INTRODUCTION

Follow this guide to replace the head strap clip on a Valve Index VR headset.

**Power off and unplug your Index before you begin your repair.**



## TOOLS:

- [Spudger](#) (1)




## PARTS:

- [Valve Index Headset Head Strap Clip](#) (1)

## Step 1 — Remove the head strap clip



- Insert the flat end of a spudger in between the bottom of the head strap clip and the head strap padding.
  - Pry up on the head strap clip until it is unclipped from the head strap.
-  To reinstall, first locate the recesses on the head strap for mounting the clip. Next, align the clip with the recesses, verify the tether cable is threaded through the clip, then simply press the clip back into place.

**To reassemble your device, follow the above steps in reverse order.**

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our Valve Index [Answers community](#) for help.