



Fairphone 4 Battery Replacement

Use this guide to replace a worn-out or dead...

Written By: Manuel Haeussermann



INTRODUCTION

Use this guide to replace a worn-out or dead battery in your Fairphone 4.

If your battery is swollen, [take appropriate precautions](#).



TOOLS:

- 1 x Opening Picks (1)

optional



PARTS:

- Fairphone 4 Battery (1)

Step 1 — Pry the back cover up



 Be sure to power off your phone before you begin.

- Insert your thumbnail, or a prying tool like a spudger, into the notch at the bottom right of the back cover.
- Pry the back cover up to start separating its plastic clips.

Step 2



- Using your thumbnail or an opening pick, slide along the right side of the phone to loosen the plastic clips.

Step 3



- Slide along the bottom of the phone to loosen the plastic clips.

Step 4



- Slide along the left side of the phone to loosen the plastic clips.
 - Lift the back cover to release the rest of the plastic clips and remove it.
- i** To reinstall the back cover press it firmly into place until you hear a snap from the plastic clips.

Step 5 — Lever up the Battery



- Use a fingernail or a prying tool at the marked notch to lever the battery out of its recess.
- Lift the battery out of its recess and remove it.
- Remove the battery.

For optimal performance, [calibrate your newly installed battery](#) after completing this guide.

To reassemble your device, follow these instructions in reverse order.

Take your e-waste to an [R2 or e-Stewards certified recycler](#).

Repair didn't go as planned? Try some [basic troubleshooting](#), or ask our [Answers community](#) for help.