



iMac Intel 27" EMC 2309 and 2374 Access Door Replacement

iMac Intel 27" EMC 2309 and 2374 Access Door replacement.

Written By: Andrew Bookholt



INTRODUCTION

Remove the access door to replace RAM modules.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Access Door



- Loosen the three Phillips screws securing the access door to the bottom edge of your iMac.
- ⓘ These screws will remain captive in the access door.
- Remove the access door from your iMac.
- ⚠ During reassembly, fasten the access door loosely and align it with the pocket cut into the outer case of the iMac before fully tightening the screws.

To reassemble your device, follow these instructions in reverse order.