



Velocity NoteMagix M10 A82 Battery Replacement

There is a latch and a battery lock keeping the battery in place.

Written By: Sam Middleton



INTRODUCTION

You will use your hands to remove the power source of the notebook. A very simple task to complete.

Step 1 — Battery



- Place the notebook on the table, with the battery facing away from you.
- Slide the switch from "lock" to "unlock" with your right hand on the right side of the computer.
- Maintain holding the right switch in the "unlock" position.
- Use your left hand to slide the left switch from "lock" to "unlock".

Step 2



- Maintain both left and right switches in the "unlock" position.
- Use your forefingers to push the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.