



Canon EOS Rebel T4i Rubber Grips Replacement

This particular camera has three rubber grips, and with this guide users can replace the grips that have become worn-down or over-used.

Written By: Brooke Patterson



INTRODUCTION

In this guide, users can replace the rubber grips.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Removing the Rubber Grips



- Use the spudger to pry at the loose edges of the rubber grip.
- Continue to pull upward until the rubber grip is completely off.
- Repeat the first step to remove any, or all, grips you want to replace.

To reassemble your device, follow these instructions in reverse order.