

Sony Xperia Z Display Assembly Replacement

Sony Xperia Z Touch Screen Glass Digitizer & LCD Display Replacement

Written By: ZFix

SONY XPERIAZ





touch screen & LCD dysplay replacement

INTRODUCTION

Also known as Xperia Z LT36i, Xperia C6603, Xperia C6602, Xperia Z LTE, Xperia Z HSPA+

How to change broken, not working Digitizer or Display.

This procedure is very hard. You must have experience to do this.

Please SUBSCRIBE to my channel ツ

[video: https://www.youtube.com/watch?v=PhG6Mvxsa1s]



TOOLS:

- iFixit Opening Tools (1)
- Spudger (1)
- Phillips #0 Screwdriver (1)
- Tweezers (1)




PARTS:

Sony Xperia Z Rear Cover Adhesive (1)

Step 1 — Touch Screen Glass Digitizer & LCD Display








Warm the Battery cover before disassemble it.

Step 2








'Carefully' warm the battery too









• Unscrew 4x screws and disconnect 3x flex cables in case to free the mother board.


Step 4








- This are: main Camera, front Camera and antenna wire Flex cable.
- Now we can remove the Motherboard.










Guide ID: 25501 - Draft: 2017-12-05

The Headphone connector and the Ringer / Cover / Signal Antenna module.

Step 6







 Disconnect the LCD light flex cable by lifting up the black plastic and removing the flex cable from the right side and we are ready to go.








• Warm the **Touch screen** before you start to disassemble it.


Step 8









Let's assemble the new spare part.







- All's well, that ends well. :)
- Did you do it successfully?
- Please SUBSCRIBE to my channel ツ

To reassemble your device, follow these instructions in reverse order.