



Garmin Forerunner 405 Button Replacement

This guide will walk you through the process of...

Written By: Kyle Kiwczak



INTRODUCTION

This guide will walk you through the process of replacing a button on the Forerunner 405.

TOOLS:

Phillips #000 Screwdriver (1)

Tweezers (1)

Step 1 — Unscrew backing




- Unscrew the four 6.35 mm Torx T5 screws securing the backing of the watch.

Step 2 — Separate Component




- Pull the backing off the watch.

Step 3 — Separate





- Pull the battery wires out from the motherboard slowly.

Step 4 — Unscrew



- Unscrew one 4 mm philips screw that attaches the motherboard using a PH000 screwdriver.
- Lift the motherboard out of the watch.

Step 5 — Pull apart



- Push button in and pinch silver clip with [tweezers](#).
- Pull silver clip off the pin it is on.
- Pull out button and replace.

To reassemble your device, follow these instructions in reverse order.

