



Canon PowerShot A630 Zoom Lens Ring Replacement

This guide will show you how to replace your zoom lens ring if it is damaged.

Written By: Alicia Burns



Step 1 — Zoom Lens Ring



- Press down on the indicated button.
- While still pressing down on the button, grip the edges of the zoom lens ring and turn counterclockwise.

Step 2



- Lift the zoom lens ring to remove it.

To reassemble your device, follow these instructions in reverse order.