

Motorola Photon 4G MB855 Headphone Jack Replacement

How to replace the Headphone Jack on a Motorola Photon 4G.

Written By: Eddie Krause



This document was generated on 2020-11-26 08:37:43 PM (MST).

INTRODUCTION

If you are unable to use your headphones properly, the headphone jack may be faulty and needs to be replaced. Use this guide to replace your headphone jack.



TOOLS:

- iFixit Opening Tools (1)
- Tweezers (1)
- T4 Torx Screwdriver (1)

Step 1 — Removing the Back Cover





- Insert a plastic opening tool into the indentation at the bottom of the phone between the front and rear covers.
- Lift the back cover from the bottom and remove it from the phone.

Step 2 — Removing the Battery





- Insert a plastic opening tool, or your finger, into the notch in between the sim card and the battery and lift the battery upward.
- Remove the battery from your phone.

Step 3 — Removing Screw Covers







Remove all five screw covers with tweezers located in the picture.

Step 4 — Removing the Midframe







- Remove the 10 T4 Torx screws securing the midframe to the display assembly.
- Gently pry the midframe from the display assembly and remove it.

Step 5 — Locating Headphone Jack



 Locate Headphone Jack attached to Midframe.

Step 6 — Removing Headphone Jack







Use Tweezers to gently remove Headphone Jack from the Midframe.

↑ The Headphone Jack is attached with adhesive, remove carefully.

To reassemble your device, follow these instructions in reverse order.