



PowerBook G4 Aluminum 15" 1.5-1.67 GHz Battery Replacement

Written By: iRobot



INTRODUCTION

Changing the battery is easy -- all you need is a coin or a spudger.



TOOLS:

- [Coin](#) (1)



PARTS:

- [G4 Aluminum 15" Replacement Battery \(New\)](#) (1)

Step 1 — Battery



- Use a coin or a spudger to turn the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.