



Nintendo 2DS Battery Replacement

This guide illustrates how to remove the upper...

Written By: Fina Beauchamp



INTRODUCTION

This guide illustrates how to remove the upper rear panel from the Nintendo 2DS to access the battery and other parts of the device.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)



PARTS:

- [Nintendo CTR-003 Battery](#) (1)

Step 1 — Battery



- Remove the two Phillips captive screws securing the upper rear panel.
- ⓘ The captive screws will not completely detach from the back panel.

Step 2



- Hinge the upper rear panel upwards and outwards to remove it.

Step 3



- Remove the battery from its housing by lifting it up from the side closest to the outside edge.

To reassemble your device, follow these instructions in reverse order.