



iRobot Roomba 655 Pet Series Filter Replacement

How to remove you dust bin in order to clean it out.

Written By: Matt Davis



INTRODUCTION

It is recommended to empty and clean the dust bin often. This will keep your Roomba at its peak performance.

Step 1 — Filter



- Grasp the back of the Roomba
 - Push the button with your thumb
 - Remove the dust bin by simply pulling out
- i** Be careful not to pull to hard as not to have dust/dirt fall out.

Step 2



- To open the gate, push the yellow tab and pull it open
- Push in the two yellow tabs on the filter and pull it out gently

To reassemble your device, follow these instructions in reverse order.