



Skytex SP728 Case Replacement

This guide will show users how to replace the back case of the device.

Written By: Michelle Strickland



INTRODUCTION

How to remove the back case of the tablet.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Case



- Make sure the device is powered off
- Rotate the device so the ports and screws face you

Step 2



- Using a small phillips screwdriver, unscrew both end screws

Step 3



- Using a plastic opening tool, work your way around the edge of the device, separating the case from the rest of the device

Step 4



- Once the case has been loosened, pry the backing off gently with your hands.
- ⚠ Make sure to remove the case gently as extra force can break the clasps or the case itself.

To reassemble your device with a new case, follow these instructions in reverse order.