

Moultrie I45 GameSpy Casing Replacement

Removing the case to access the interior

Written By: Sean Hill



INTRODUCTION

This guide details how to remove the camera's case.



TOOLS:

• Phillips #000 Screwdriver (1)

Step 1 — Casing



 Using a Philips head screwdriver, remove the eight 6mm screws located at the bottom of the device.

Step 2



 Remove the butterfly nut from the lid arm.

Step 3



Remove the lid-covering.

Step 4



 Using a Phillips head screwdriver, remove the six 4mm screws from the face of the camera.

Step 5



- Gently separate the two halves of the case.
- The two halves are connected by a wire. Pulling too roughly can damage the wires and cause the camera to stop functioning.

To reassemble your device, follow these instructions in reverse order.