

Disassembling Audiovox T752 Back Panel

Removing the back panel of your Audiovox T752.

Written By: Logan





• iFixit Opening Tools (1)

Step 1 — Back Panel







- Find a good spot to fit the pry bar between the back cover and tablet. Slowly drag the pry bar along the sides of the cover.
- NOTE: some force will need to be used to remove the cover. Avoid excessive force.

To reassemble your device, follow these instructions in reverse order.