

Nokia Lumia 620 Loudspeaker Replacement

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.

Written By: ZFix



INTRODUCTION

How to disassemble the phone and replace the Loudspeaker / Buzzer / Ringer.



TOOLS:

• T4 Torx Screwdriver (1)



PARTS:

Nokia Lumia 500 610 620 720 820 920 925 (1)

Step 1 — Loudspeaker







- Switch off the phone, remove the battery and SIM (Memory) card.
- The lower back cover is held by 3x T4 Torx screws.
- The screws are of two types!

Step 2



 The Loudspeaker is on the lower back cover.

To reassemble your device, follow these instructions in reverse order.