



# Nextbook 8 Screen Replacement

Step by step guide to replace the Nextbook 8 screen.

Written By: Dylan Wiese



# INTRODUCTION


You need a thin tool to get the back cover off. If a plastic opening tool is not available, a guitar pick works just fine. Use caution when removing the back cover and inside parts.

---

## TOOLS:


- [iFixit Opening Picks set of 6](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Battery




- Use the plastic opening tool to remove the back cover. Carefully slide the tool between the front glass and back cover.
- Slide the tool along the edge to work the back cover off.
- ⓘ It helps to have an extra tool to stick in the gap and keep the back cover separated from the glass as you slide the other tool.

## Step 2




- Remove the tape covering the motherboard.
- Remove the silver tape holding the white ribbon cables to the battery.

## Step 3



- Use a spudger to carefully disconnect the battery connector from the motherboard.
- ⚠ When working with electronics, it's important to choose a tool that's ESD-safe to avoid accidental damage to the device. The regular black nylon spudger or a plastic opening tool should be used whenever possible.

## Step 4




- Use a spudger to lift up the black bar on the two ZIF connectors located above the battery.
- Pull the ribbon cables out of the connectors with tweezers or two fingers.

## Step 5





- Using the flat end of a spudger, carefully work the spudger under the battery, lifting it off of the device.
- ⓘ The battery is very malleable, so do not try to pull it off all at once.

## Step 6 — Screen




- Remove the silver and gold sticker at the bottom of the device.
- ⓘ Hold the brown circuit board down with your finger while you remove the sticker

## Step 7





- Use a spudger to lift up the black tabs on the three ZIF connectors.
- Use ESD safe tweezers to pull the ribbon cables out of the three connectors.

## Step 8




- Remove the 5 black screws on the motherboard.
- Carefully lift the motherboard off of the device and remove.

## Step 9



- Remove the two screws that hold the brackets in place.
- Remove the two silver brackets that hold the screen in place.

## Step 10




- Remove the one silver screw on the small green circuit board at the bottom of the device.
- Set aside the small circuit board for now.

## Step 11



- Remove the two silver screws from the bottom of the device.

## Step 12



- With the device face down, use a spudger to lift the screen off of the glass from the right side.

To reassemble your device, follow these instructions in reverse order.