



Sony VAIO PCG-3E2L Battery Replacement

The purpose of this guide is to help the reader replace the battery of the device.

Written By: Chengyang Chen



INTRODUCTION

This guide will aid readers to replace the battery of the device when the battery is not functioning properly.



PARTS:

- [VGP-BPS13/S Battery](#) (1)
-

Step 1 — Battery



- Put the lock switch to the left to unlock the safety lock.

Step 2



- Push the release switch to the left and hold it.
- While holding the release switch to the left, lift the battery.

To reassemble your device, follow these instructions in reverse order.