



Android tablet Nobis NB09 Button Replacement

Open the Nobis NB09 tablet and replace broken or damaged buttons.

Written By: Jackson McAdams



INTRODUCTION

This guide demonstrates how to safely disassemble a Android tablet Nobis NB09 in order to replace broken or non-functional buttons.

TOOLS:

- [Spudger](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Button



- Use a screwdriver to remove the two 00 Phillips screws on the right side of the tablet.

Step 2



- Use the plastic opening tool to loosen, and pry off the back case.
⚠ Use caution when prying around the tablet ports so they do not crack.

Step 3



- The buttons are located on the bottom left hand corner of pink back plate. Simply pop old buttons out with spudger or similar tool.

To reassemble your device, follow these instructions in reverse order.