



GoPro Hero3+ Black Edition Battery Replacement

This guide will illustrate how to access and remove the battery for the GoPro Hero3+ Black Edition.

Written By: Chad Carlson



INTRODUCTION

Can't seem to charge your battery? It may be time to replace it. This guide will walk you through the simple steps to access and replace your GoPro battery.



PARTS:

- [GoPro Hero3/3+ Replacement Battery](#) (1)
 - [GoPro Hero3/3+ AHDBT-301 Battery](#) (1)
 - [GoPro Hero3/3+ AHDBT-302 Battery](#) (1)
-

Step 1 — Battery



- Pull the tab on the back of the device to release the back cover. It should come right off.
- ⓘ The device pictured does not include the back cover.

Step 2



- Use the battery tab to pull the battery out of the device.

Step 3



- Remove the battery from the slot.

To reassemble your device, follow these instructions in reverse order.