



Pentax PZ-10 Flash Bulb Replacement

This guide will help the user replace the flash bulb.

Written By: Bryan Sugiarto



INTRODUCTION

If the flash is no longer functioning after continued use, the flash bulb may need to be replaced.



TOOLS:

- [64 Bit Driver Kit](#) (1)
-

Step 1 — Opening the Flash Bulb



- With the camera facing you, open the flash bulb by pushing the grey button to the right of the logo.

Step 2 — Unscrew Flash Bulb



- Remove the two 5.5 mm JIS #0 screws on the sides of the flash assembly.

Step 3 — Remove Flash Bulb Cover



- Gently pull off the flash cover. It should come free with very little force.

Step 4 — Flash Assembly



- The flash bulb assembly is now ready for replacement

To reassemble your device, follow these instructions in reverse order.