



Minolta Maxxum STsi Clock Battery Replacement

This guide will show you how to replace your camera's clock battery.

Written By: Conner Lawston



INTRODUCTION

If the camera's internal clock has stopped working or showing time, it may be necessary to replace the clock battery on the inside of the camera.



TOOLS:

- [Coin](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Clock Battery



- Press up firmly on the back-cover release on the right side of the camera to release the back panel.

Step 2



- Use a coin to twist open the battery compartment (twist counterclockwise).

Step 3



- Use tweezers to lift off the battery compartment cover.

Step 4



- Use tweezers to take out the old clock battery and replace it with a new one.

To reassemble your device, follow these instructions in reverse order.