

Huawei Phone p7 Power Flex Replacement

Written By: Sophia





PARTS:

Heat Gun (1)
Suction Handle (1)
iFixit Opening Picks set of 6 (1)
Tweezers (1)

Huawei Ascend P7 power fle (1)

Step 1 — Power Flex







Remove back cover.

Step 2





• Use the <u>tweezers</u> or some tools thin and sharp to cut the adhesive between power flex and bracket. And then pry it up and remove it.

