



MacBook Air 11" Late 2010 Lower Case Replacement

Remove the lower case on your MacBook Air 11" Late 2010.

Written By: Andrew Bookholt



INTRODUCTION

Remove the lower case to access the internals of your MacBook Air.



TOOLS:

- [P5 Pentalobe Screwdriver Retina MacBook Pro and Air](#) (1)



PARTS:

- [MacBook Air 11" \(Late 2010-Mid 2011\) Lower Case](#) (1)
- [MacBook Air Rubber Feet](#) (1)

Step 1 — Lower Case



- ✦ Before proceeding, close your computer and lay it on a soft surface top-side down.
- Remove the following ten screws:
 - Two 8 mm 5-point Pentalobe screws
 - Eight 2.5 mm 5-point Pentalobe screws
- ⓘ The special screwdriver needed to remove the eight 5-point Pentalobe screws can be found [here](#).

Step 2



- Wedge your fingers between the display and the lower case and pull upward to pop the lower case off the Air.
- Remove the lower case and set it aside.

To reassemble your device, follow these instructions in reverse order.