



Sony CFD-6 cdTeardown

Written By: jman



INTRODUCTION

This is a teardown of the Sony CFD-6 CD Radio Cassette-Corder.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [8" Needle Nose Plier](#) (1)
-

Step 1 — removing the antenna



- Remove 1 screw to remove the antenna.

Step 2 — remove the screws that hold this thing together



- remove 6 screws

Step 3



- Open up the place where you put tapes
- After that, pull it apart