



Etekcity Lasergrip 1080 Battery Replacement

This guide will teach you how to replace the...

Written By: Patrick Crawford



INTRODUCTION

This guide will teach you how to replace the battery if it is dead. It will require no tools and has no hazards.

⚙️ PARTS:

9V Battery (1)

Step 1 — Battery



- Pull the battery cover away from the handle by gripping near the thumb groove.

Step 2



- Gently pull the battery out of the handle.

⚠ Excessive force could damage wires.

Step 3



- Disconnect the battery by pulling the connector away from it.
 - Positive first
 - Negative second

⚠ When replacing the battery, this order is reversed.

To reassemble your device, follow these instructions in reverse order.