



Magic Bullet MB1001B Base Gear Replacement

Replacing the base gear on your Magic Bullet MB1001B.

Written By: Jackson Wiley



INTRODUCTION

Is your base gear worn down or broken? This guide will help you replace the base gear.



TOOLS:

- [Flathead Screwdriver](#) (1)
 - [Slip Joint Pliers](#) (1)
-

Step 1 — Base Gear



- Use pliers to grip the gear inside of the top of the device.
- ⓘ You may have to remove a sticker that is covering the slit at the center of the bottom before completing the next step.
- Insert a flathead screwdriver into the slit at the bottom of the device while still holding the pliers in place gripped on the gear.
- Lay the device on its side. Holding the screwdriver stationary to hold the bottom side in place, use the pliers to unscrew the gear by turning the pliers **CLOCKWISE**.

To reassemble your device, follow these instructions in reverse order.