



De'Longhi EC155 Water Reservoir O-ring Replacement

Replace the water tank o-ring to stop leaks.

Written By: David Griffith



INTRODUCTION

Replacing the o-ring is simple. This would be done to replace a damaged or dried o-ring.

Step 1 — Water Reservoir



- Flip open the top panel to reveal water reservoir.
- Grab the water reservoir by the handle and lift out.

Step 2 — Water Reservoir O-ring



- Reach into the reservoir while holding it from the bottom.
- Push up the piston.
- While pushing the piston up, pull the O-ring out.

To reassemble your device, follow these instructions in reverse order.