




LG Optimus F3 Motherboard Replacement

Replace the upper motherboard on LG Optimus F3.

Written By: Battsooj Bayarsaikhan



INTRODUCTION

In this step-by-step guide, you will be able to successfully replace your motherboard in your LG Optimus F3 device.



TOOLS:

- [iFixit Opening Tools](#) (1)
- [64 Bit Driver Kit](#) (1)
- [Tweezers](#) (1)



PARTS:

- [Replacement motherboard](#) (1)

Step 1 — Motherboard




- Turn the device so that the back faces up.
- ⓘ It is easiest to open the case near the charging port located at the bottom of the phone.
- Remove the back case by pushing up on the back and pulling down on the face as illustrated in the image.

Step 2



- ⓘ With back case removed, the battery is visible. The battery is the large square object.
- Remove the battery by flipping the bottom edge upward to separate the battery from the case.

Step 3



- Remove 10 1.0 mm screws located on the back of the device.
- ⓘ Refer to the outlined locations in the image for the screws.

Step 4



- Use the plastic opening tool to separate the inner case from the device.
- Wedge the plastic opening tool between the case.
- Wiggle the tool and use leverage to pry the case apart.

Step 5



- ❗ The camera unit is located at the top left of the phone. The camera is a silver box with a black lens. The image pin points where the camera is on the motherboard.
- Use the plastic opening tool to separate the camera from the motherboard.
- Wedge the plastic tool between the camera and the motherboard to loosen the camera unit.

Step 6




- Use a pair of tweezers to disconnect and remove the rear facing camera.

Step 7



- Use the plastic opening tool to separate the sim card and the memory card connector from the motherboard.
- ⚠ Note that the sim card and the memory card connector are one unit.
- Wedge the plastic tool to lift up the sim-memory unit from the motherboard.

Step 8



- Use the plastic opening tool to remove the charging port unit.
- Wedge the plastic opening tool between the charging port unit and the motherboard to separate the port.

Step 9



- Use the plastic opening tool to remove the motherboard located directly above the battery encasement.
- ⓘ The motherboard is an L-shaped unit above and to the left of the battery encasement.
- Wedge the plastic opening tool between the circuit board and the motherboard to separate the unit.

To reassemble your device, follow these instructions in reverse order.